



# INSTALL INSTRUCTIONS

USP TEAR-DUCT DIRECT FLOW INTAKE SYSTEM

7716 WILES RD. CORAL SPRINGS, FL 33067

[WWW.USPMOTORSPORTS.COM](http://WWW.USPMOTORSPORTS.COM)

## WHAT'S INCLUDED:

1. CARBON FIBER FILTER
2. TEAR-DUCT
3. 3" HOSE COUPLERS X2
4. 3" HOSE CLAMP X4

## TOOLS REQUIRED:

- PLIERS
- T-25 TORX
- T-30 TORX
- 7MM SOCKET
- 8MM SOCKET



1. Remove the factory intake snorkel by popping off the top cover and removing the intake pipe.



2. Remove T-30 screw securing the factory airbox.



3. Grasp the airbox and pull to remove the airbox.



4. Remove the 2 T-25 torx screws securing the front intake snorkel.



5. Install the USP tear-duct with the screws removed in the previous step.



6. Push (optional) breather filter onto small hose until it pops in place.



7. Secure breather filter and hose under battery tray away from moving parts and shifter cables.



8. Loosely install 3" silicone hose couplers and hose clamps.



9. Install the filter assembly with tip of the inner cone facing forward (as shown) to the tear duct. Then insert the open end of the filter assembly to the rear silicone.



10. Adjust the intake system and tighten all hose clamps.

