



INSTALLATION INSTRUCTIONS

USP TRACKSWITCH WIRELESS BURNOUT BOX FOR AWD

SKU# 26355 MFG# USP-601

INSTRUCTIONS ARE ALSO AVAILABLE ONLINE FOR A MORE ENHANCED VIEWING.
PLEASE VISIT WWW.USPMOTORSPORTS.COM AND SEARCH SKU# 26355



Please note this kit is for off-road use only. It does not require a power cycle to function, but a cycle is necessary to clear dashboard lights. Several dash errors will be displayed when enabling FWD mode, these are temporary. After using this kit and putting your car back to AWD mode, simply enable the parking sensor (if applicable), then power cycle the car. Do not attempt to use this switch while driving.
The vehicle must be stopped and either in neutral or park.

TOOLS REQUIRED

- NONE

WHAT'S INCLUDED

- (1) WIRELESS SWITCH (PLUG AND PLAY)
- (2) WIRELESS RF REMOTES (1 WITH DOUBLE SIDED TAPE INSTALLED)
- "REMOVE BEFORE LAUNCH" KEYCHAIN

THIS MATERIAL IS FOR REFERENCE ONLY. IMPROPER INSTALLATION OR MISUSE OF THIS PRODUCT COULD RESULT IN FAILURE OR DAMAGE. USP MOTORSPORTS IS NOT RESPONSIBLE FOR ERRORS OF INSTALLATION, LOSS OR DAMAGES RESULTING FROM DEPENDENCE ON THIS MATERIAL.

888.755.7772 /// 1919 NW 40TH COURT, POMPANO BEACH, FL 33064 /// WWW.USPMOTORSPORTS.COM

INSTALLATION INSTRUCTIONS

USP TrackSwitch Wireless Burnout
Box for AWD

USP motorsports

2

1. Unclip and remove plastic anchor covers located along the bench by pushing the clip down, then pulling straight out.



2a. *Seat removal demonstrated is on a MK7 Golf R, the process is very similar on most Volkswagen and Audi Models. To remove the seat you must release the two retaining clips located in the areas marked below. (Next step on how to remove)



2b. To remove the rear seat pull the bench straight up in the areas indicated in step 2a. If the seat is being difficult to remove try pulling back on the seat while you lift upwards.



3. Locate the plastic panel on the driver's side and remove by simultaneously pushing forward and pulling upwards on the bottom of the panel, revealing the D-Connector.



4. Unplug the D-Connector.



5. Connect both ends of the D-Connector into their respected slot on the Burnout Box. Then tuck away into the panel and close back up. Reinstall the seat and plastic covers and then your all done!



6. *** Please note that your vehicle will not reset to AWD on it's own when the vehicle shuts off. Example: If the you shut the vehicle off with FWD enabled. The next time you start your vehicle it will be in FWD.



7. Have FUN!!!

